

Dual-chamber bottle

Ideal packaging solution for separate storage of liquid and powder products. Proprietary design ensures sterility of products until use



OVERVIEW



- **Reservoir chamber on top, primarily container on the bottom.**



- **1.5 g powder reservoir.**



- **Dropper tip is used as dispenser.**



- **Product is reconstituted within the bottle before dispensing**, maintaining the sterility of the contents.



- **Tamper-evident closure** ensures inviolability of the contents.



- **Customizable** to store liquid-liquid products instead of liquid-powder configurations.

MARKETS



Eye Drop



Cosmetic



Pharmaceutical



Medical Device

FEATURES

How it works:

1. Tear strip is removed.
2. Pressing down on the cap perforates the internal membrane, allowing the powder in the reservoir to flow into the primary bottle.
3. Mix the contents by shaking the bottle.
4. Remove the cap.
5. Dispense the product.



For additional information, please visit:
tekni-plex.com/healthcare